

# DENT PULLER

Model No: CHT 273

**PULL OUT PERPENDICULAR  
TO PANEL**



- \* Ensure the panel is clean, and dust free.
- \* Ensure the rubber pad is clean and dust free.
- \* Can be used where no kinks or creases are in evidence.
- \* Press the rubber pad down firmly, centered on the dent.
- \* Pull perpendicular from the panel. Extra purchase may be achieved using an appropriate tool through the handle, where necessary.
- \* To release the pad, pull upwards on one edge.

**RELEASE FROM EDGE**

