

Chantrol® STRONG-ARM



ALUMINIUM FOLDING SACK TRUCKS

MODEL NO: CTSTF4, 5B & 6B

PART NO: 6500790, 6500795 & 6500796

USER INSTRUCTIONS

ORIGINAL INSTRUCTIONS

GC0619 rev 4

INTRODUCTION

Thank you for purchasing this CLARKE Folding Sack Truck.

Before attempting to use this product, please read this manual thoroughly and follow the instructions carefully. In doing so you will ensure the safety of yourself and that of others around you, and you can look forward to your purchase giving you long and satisfactory service.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

ENVIRONMENTAL PROTECTION

Do not dispose of this product with general household waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of appropriately.

SPECIFICATIONS

		CSTF4	CSTF5B	CSTF6B
Maximum Rated Load Capacity		60 kg	90 kg	200 kg
Dimensions (L x D x H) mm	Open	420 x 400 x 1000	445 x 500 x 980	600 x 600 x 1280
	Closed	385 x 55 x 635	500 x 60 x 730	590 x 80 x 1020
Weight		3 kg	4.5 kg	9.5 kg

Please note that the details and specifications contained herein, are correct at the time of going to print. However, CLARKE International reserve the right to change specifications at any time without prior notice.

SAFETY PRECAUTIONS

1. Keep the work area tidy & well lit.
2. Keep children and visitors away from the work area.
3. Never carry out any alterations or modifications to this product.
4. Do not exceed the stated capacity of the truck.
5. Load the platform evenly with the centre of gravity of the load over the centre of the platform.
6. Do not bounce the truck over rough ground, or down curbs etc. Use ramps wherever possible.
7. Do not drop or lay the trolley down when heavily loaded.
8. Do not transport a tall load which may impair your forward view.
9. Take extra care if transporting a wide load.
10. Always ensure the load is stable before attempting to move the truck.
11. Take care that the heaviest part of a tall load is to the bottom of the truck touching the frame. When stacking loads ensure that the height of the stack does not extend above the handle.

Please keep these instructions in a safe place for future reference.

FOLDING & UNFOLDING THE TRUCK

CSTF4-to extend the handle pull the cross-beam upwards until the handle locks into position. To lower the handle, pull the cross-beam in an upwards direction and then lower. To unfold the platform, simply push it down until it snaps into place and the wheels automatically open out.

CSTF5B-press the button in the centre of the cross-beam and pull the handle upwards until it locks into position, then unfold the platform by pushing it down and the wheels automatically open out.

CSTF6B- to extend the handle, press the button in the centre of the cross-beam and pull the handle upwards until it locks into place. Then unfold the platform by pushing it down until it snaps into place and the wheels open out. Lift and revolve the handles to the desired position for use and fold away afterwards.

To fold the platform on any model, pull it up until it lies flat against the back support with the wheels automatically folded away and lower the handle.

A SELECTION FROM THE VAST RANGE OF

Clarke®

QUALITY PRODUCTS

AIR COMPRESSORS

From DIY to industrial, Plus air tools, spray guns and accessories.

GENERATORS

Prime duty or emergency standby for business, home and leisure.

POWER WASHERS

Hot and cold, electric and engine driven - we have what you need

WELDERS

Mig, Arc, Tig and Spot. From DIY to auto/industrial.

METALWORKING

Drills, grinders and saws for DIY and professional use.

WOODWORKING

Saws, sanders, lathes, mortisers and dust extraction.

HYDRAULICS

Cranes, body repair kits, transmission jacks for all types of workshop use.

WATER PUMPS

Submersible, electric and engine driven for DIY, agriculture and industry.

POWERTOOLS

Angle grinders, cordless drill sets, saws and sanders.

STARTERS/CHARGERS

All sizes for car and commercial use.



PARTS & SERVICE: 0208 988 7400

E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

Clarke® INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG
www.clarkeinternational.com