

WORK TABLE SUPPORTS MODEL NO: CWTS1

PART NO: 6600020

ASSEMBLY & USER INSTRUCTIONS



LS0412

INTRODUCTION

Thank you for purchasing the CLARKE Work Table Supports. Before attempting to use this product, please read this manual thoroughly and follow the instructions carefully.

GENERAL SAFETY RULES

IMPORTANT: Failure to follow these precautions could result in personal injury, and/or damage to property.

- 1. **ALWAYS** seek help when moving large items.
- 2. **ALWAYS** keep work area clean. Cluttered areas invite accidents.
- 3. **ALWAYS** keep children away from work areas.
- 4. ALWAYS keep your proper footing and balance at all times - don't overreach. For best footing, wear rubber soled footwear. keep floor clear of oil, scrap wood, etc.
- 5. ALWAYS check tools are in perfect working order before using.
- 6. **ALWAYS** check the stability of thefinished bench before use.
- 7. **ALWAYS** selectworktop and shelf materials of sufficient strength and size to support the intended load.

SPECIFICATIONS

Model :	CWTS1
Part No :	6600020

Maximum Capacity :200 kg (depending on table materials used)

ASSEMBLY

We recommend a worktop and shelf thickness of at least 18 mm.

- 1. Ensure floor is firm and level before starting.
- Place the worktop (not supplied) on top of the two work table supports as shown.

NOTE: Seek assistance if required.

- Secure the top to the work table supports using suitable nuts, bolts and washers (not supplied).
- 4. Measure and fit a shelf in the same way and secure the work table supports to the floor if required using suitable fixings (not supplied).

MAXIMUM LOAD

Whilst the work table supports have a maximum capacity of 200 kg, the maximum capacity of the finished workbench will depend on the materials used and the distance between the supports. this may be considerably less than 200 kg and is the responsibility of the user.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.



CIEPTIC INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG www.clarkeinternational.com