

Clarke®

CONTRACTOR®



85 LITRE WHEELBARROW

MODEL NO: WB85P

PART NO: 6603110

USER INSTRUCTIONS

ORIGINAL INSTRUCTIONS

DL1121 ISSUE 2

INTRODUCTION

Thank you for purchasing this CLARKE 85 Litre Wheelbarrow.

Before attempting to operate the product, it is essential that you read this manual thoroughly and carefully follow all instructions given. In doing so you will ensure the safety of yourself and that of others around you, and you can also look forward to the product giving you long and satisfactory service.

GUARANTEE

This CLARKE product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

TECHNICAL SPECIFICATIONS

	WB85P
Capacity	85 Litres
Sand Capacity	5.5ft ³
Wheel Diameter	350mm
Weight	12kg

Unpack the components onto a clean flat area and ensure that all parts are present according to the components list.

Visually inspect all components to ensure that no damage was suffered in transit. Any deficiencies should be reported to your CLARKE dealer immediately.

COMPONENTS

1



2



3



4



5



6



7



8



9




10




1	1 x Wheel	6	1 x Bucket Support Bar
2	1 x Front Frame Section	7	1 x Wheel Axle
3	2 x Rear Frame Handles	8	2 x Wheel Supports
4	1 x Bucket	9	6 x Large Bolt, Nut & Washers
5	2 x Front Support Bars	10	6 x Small Bolt, Nut & Washers

ASSEMBLY

NOTE: Hand tighten all bolts & nuts until the product is fully assembled.




1) Insert the rear frame handles (3) into the front frame section (2), aligning the holes and secure with a large bolt, nut & washers (9)




2) Fix the bucket support bar (6) between the rear frame handles (3) using a large bolt, nut & washers (9)




3) Align the bucket (4) against the frame. Secure the bucket to the frame using the small bolts, nuts & washers (10) through the 4 holes in the bottom of the bucket.



4) Attach the front support bars (5) to the remaining holes in the bucket using the small bolts, nuts & washers (10).
* = The right angle side should fit against the frame, do not attach at this stage.



5) Using a large bolt, nut & washers (9), thread the bolt through the front support bar (5), the frame and the wheel support (8) and secure with the nut. Only do this for one side.



6) Fix the axle (7) through the wheel (1). Slide the axle into the wheel support (8) secured to the frame. Fit the second wheel support, making sure the wheel and axle are supported on both sides before fixing with a nut. Tighten all bolts and nuts fully.